Quick user guide Combi 2 E UK / Combi 4 E / 6 E Version UK

Energy source selection

Rotary switch
(external ring)

LED functional display
Yellow = Electrical
operation



Electrical

Gas

Electrical + gas

≈ = 1800 W

≀ = 900 W

🔥 = 2000 W / 4000 W / (6000 W)

≀🔥 = Max. 2900 W (4900 W)

≈🔥 = Max. 3800 W (5800 W)

Operating mode

Rotary switch
(external ring)

LED functional display
Green = Operational



Warm water

Heat

60° = Water temperature 60 °C

40° = Water temperature 40 °C

○ = **Off**

🔥 = **Without**
controlled water temperature

🔥60° = **With**
controlled water temperature 60 °C

Room temperature

LED functional display
Red = Fault
Yellow = Heat-up phase
warm water



The right to effect technical modifications is reserved!

truma

34020-92600 · 00 · 07/2012 · ©

Quick user guide Combi 2 E UK / Combi 4 E / 6 E Version UK

Energy source selection

Rotary switch
(external ring)

LED functional display
Yellow = Electrical
operation



Electrical

Gas

Electrical + gas

≈ = 1800 W

≀ = 900 W

🔥 = 2000 W / 4000 W / (6000 W)

≀🔥 = Max. 2900 W (4900 W)

≈🔥 = Max. 3800 W (5800 W)

Operating mode

Rotary switch
(external ring)

LED functional display
Green = Operational



Warm water

Heat

60° = Water temperature 60 °C

40° = Water temperature 40 °C

○ = **Off**

🔥 = **Without**
controlled water temperature

🔥60° = **With**
controlled water temperature 60 °C

Room temperature

LED functional display
Red = Fault
Yellow = Heat-up phase
warm water



The right to effect technical modifications is reserved!

truma

34020-92600 · 00 · 07/2012 · ©